

CarryMe

Rear Rack Setup

1. Loosen the bolts at the back of the main frame first.
2. Secure the rack and elastic cord under tube bolts as illustrated.

