

IFMOVE mudguard installation

Step 1

Take the mudguard set out of the box (contents: mudguards (F&R), M5x20mm bolt*2, OD10mm washer*5, OD13mm washer*2). Prepare one M5 hex wrench.



Step 2 Install the front mudguard (short) Release the tire air, tighten the mudguard with bolt & washers (3~4pcs) to the front fork through the flat tire. Adjusting the washer number & position if necessary (small pic).



Step 3

Release the bolt as illustrated. Take the outside grey and black thick washers out



Step 4

Fit the front mudguard in position, tighten back the bolt with one OD13mm washer.



Step 5 Install the rear mudguard (long)

Tighten the bolt to the rear fork with one OD10mm washer.



Step 6

Release the upper bolt of brake caliper as illustrated



Step 7 Take the thick black washer out and fit the mudguard support. Tighten back the bolt with one OD13mm washer.



Step 8

Pump the front tire and the bike is ready to ride.



IFMOVE 土除安裝說明

步驟 1

將土除組自包裝取出(內含:前土除(短), 後土除(長), M5x20mm 螺絲*2, 外徑 10mm 墊圈*5, 外徑 13mm 墊圈*2), 準備一支 M5 內六角扳手工具。



步驟 2 安裝前土除(短)

將前輪消氣, 扳手穿過土除與輪胎間隙將 M5x20 螺絲連同 3~4 片外徑 10mm 墊圈鎖緊。視土除與前輪的相關位置增減墊圈數量或調整墊圈在土除取付左右側的分配(小照片)。



步驟 3

如圖示將螺絲鬆開, 取出靠外側的兩片凹凸華司(黑、灰)。



步驟 4

將前土除取付連同 1 片外徑 13mm 墊圈放入再以原螺絲鎖緊。



步驟 5 安裝後土除(長)

如圖先將後土除前端取付以 M5x20mm 螺絲與 1 片外徑 10mm 墊圈鎖入後叉下方螺絲孔。



步驟 6

鬆開圖中碟剎卡鉗上方位置螺絲。



步驟 7

螺絲取出後拿掉下方黑色厚墊圈放入土除取付及 1 片外徑 13mm 墊圈再以原螺絲鎖緊。



步驟 8

將前輪打氣至合適胎壓後即可騎乘。

