

Pacific CARRYME 2014

Owner manual



Assembly Procedures

Step 1:

Unpack the box – a 100% assembled bike, and a seat assembly



Step 2:

Open the QR lever, lift up and turn the handlebar 180 degree clockwise. Hold the handle and open wide to maximum, then close the QR lever.



Step 3:

Open the QR lever on the seat tube, insert the seat post and close the QR lever.



Note:
Do not raise the seat higher than the minimum insertion mark.

Step 4:

Swing the seat tube backwards. Lock the seat stays to the seat tube.



Step 5:

Release the headtube clamp bolt and open the spring latch.



Step 6:

slide the headtube clamp toward the bottom of the head tube, and tighten the wing bolt with your fingers.



Step 7:

Adjust the height and alignment of handlebar and seat.



Note:
Do not raise the seat higher than the minimum insertion mark.

Step 8:

Press and open the pedals.



Step 9:

Use 5mm hex wrench to adjust the brake lever to optimum position



How to fold

Step 1:

Loosen the head tube clamp bolt one turn, slide the head tube clamp to top by pushing the seat backward, latch the head tube to the frame. Mantinee unlock the seat stays from the seat tube.



Step 2:

Pull the seat toward the handlebar, open the seat QR lever, lower the seat and turn it side ways, latch the QR lever to the frame.



Step 3:

Open the stem QR lever, lower the stem and turn the handlebar top of the saddle, close the QR lever.



Step 4:

Press the pedals and fold.



You are now ready to pull/push it or carry it!



Don'ts!

- Don't exceed the maximum load limits.
- Don't carry a person or a pet on the rear carrier.
- Don't perform stunt riding.
- Don't jump over curves.
- Don't raise the handlebar stem beyond the height limit.
- Don't raise the seat post beyond the height limit.
- Don't over stress any of the QR levers.
- Don't ride it off-road.

Important Safety Checklist!

- Check and make sure that all clamps are properly tightened.
 - 1) The handlebars should be tight with no play.
 - 2) The head tube clamp should be fully tightened not allowing rotation or play.
 - 3) The seat stay clamp should be fully tightened (step 4).
 - 4) The seat post clamp should be fully tightened not allowing any rotation or sliding.
- Do not raise the handlebar stem and seat post up beyond the maximum insertion mark.
- Always wear a helmet and abide by all traffic regulations and courtesies!
- Rear carrier max. loading: 10kg / Average speed: 13km/h
- Rider height: 145-185cm / Max. loading: 100kg (rider + luggage)

Important Maintenance Checklist!

- 1st service inspection after at most 300 km or at latest one months after purchase, repeat every 3 months.
- Parts need lubrication: chain, headset, bearings.
- Parts prohibit lubrication: seatpost, seat tube, adjustable stem, rims.
- Repeat lubrication every half month or after at most 150 km ride.
- Apply lubrication immediately after washing or riding in rainy day.



686, Yongfu Rd., Yong An,
Xinwu, Taoyuan 327, Taiwan
Tel: +886-3-4861231 Fax: +886-3-4861215
Web: <http://www.pacific-cycles.com>
Email: team@pacific-cycles.com